

Multi-Drawer Lock Fitting Guide

The Lowe & Fletcher Multi-Drawer lock can be fitted in a few seconds and is used in conjunction with a simple locking bar (not-supplied) which is fitted with pegs. By turning the key 180° the roller cam on the back of the lock moves the bar downward and the peg engages in the spring steel catch plate fitted on the side of the drawer and thus prevents the drawer being pulled out.

In the open position the roller cam moves past top dead centre which prevents the bar from dropping and accidentally locking the cabinet.

